
# Introduction to IPv6

Structure and function of IPv6 addresses

## **Network Addresses**



## Let's look at an address

#### What is this?

1600 Pennsylvania Ave NW Washington, DC 20500

#### Private vs. Public Addresses



#### **Public:**

1600 Pennsylvania Ave

NW, Washington, DC 20500



#### **Private:**

P.O. Box 27624 Washington, D.C. 20500

## Sample IPv4 Addresses




192.168.1.1

10.12.15.201

201.23.5.104

## Sample IPv6 Addresses



3FFE:52AB:2:ABC:123:56:DE:1

2001::2:ABC:123

FE80::1234:1

FF01::2

• •

## **Sample Private Addresses**

192.168.1.1

•IPv4

Private

FE80::1234:1

- IPv6
- Private (limited)

## **Sample Public Addresses**


201.23.5.104

2001::2:ABC:123

- •IPv4
- •Public

- IPv6
- Public

## **TCP/IP Network**



192.168.1.100

2001:5c0:8fff:3::100

192.168.1.101

2001:5c0:8fff:3::101

192.168.1.102

2001:5c0:8fff:3::102

## **Addressing Concepts**

Decimal notation (IPv4) 1.2.3.4

> Hexadecimal notation (IPv6) 00 - FF

> > Binary
> >
> > 1 byte = 8 bits

## **IPv6 Address Representation**

IPv4 Address: 32 bits - IPv6 address: 128 bits

- IPv6 address: 8 sections of 4 hex digits (16 bits)
  - 1111:2222:3333:4444:5555:6666:7777:8888
- Zero-compression
  - 1111:2222:**0:0**:5555:6666:7777:8888
  - 1111:2222::5555:6666:7777:8888
- Prefix length
  - 1111:2222::5555:6666:7777:8888 /64
- Prefix alone
  - 1111:2222:: /64

/8	11111111xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx	Important IPv6 Prefix Notations
/16	11111111111111.xxxxxxxxxxxxxxxxxxxxxxx	0000:: FFFF::
/32	111111111111111. 1111111111111.  XXXXXXXXXX	0000:0000:: FFFF:FFFF::
/48	111111111111111.1111111111111. 11111111	0000:0000:0000:: FFFF:FFFF:FFFF::
/56	1111111111111111.1111111111111. 11111111	0000:0000:0000:00xx:: FFFF:FFFF:FFF:FFxx::
/64	111111111111111.11111111111111. 11111111	0000:0000:0000:: FFFF:FFFF:FFFF::

## **Zero Compression**


 IPv6 addresses are zero compressed.


 Double colon can appear only once.

Zero compression of special addresses.


```
805B:2D9D:DC28:0:0:FC57:0:0
  805B:2D9D:DC28::FC57:0:0
           or
805B:2D9D:DC28:0:0:FC57::
  FF00:4501:0:0:0:0:0:32
       FF00:4501::32
       0:0:0:0:0:0:0:1
       0:0:0:0:0:0:0:0
```


#### **IPv4 / IPv6 Address Structure**





## **IPv6** Address Types





**Anycast addresses appear the same as unicast addresses** 

## Importance of IPv6 Network Prefix

• First part of network prefix important!

• Example: 2001:5c0:8fff:3::3f53

- Learn:
  - Can you go out on the internet with it,
  - What devices can you talk to,
  - Is it for special function.

FE80 = Link Local

**FFxx** = **Multicast** 

2001 = Global Unicast

**0000** = Special

## **Addressing Changes**

No broadcast addressing in IPv6 IPv4 Broadcast Addresses

IPv6 multicast addressing used

192.163,17255 255.257.255.255

## **Addressing Planning**

- \*IPv6 address planning is different from IPv4
- •IPv4: 0 address is network, .1 address is gateway, 255 is broadcast (generally)
- \*IPv4 and IPv6 subnet structure is different
- Basically, you do not lose three addresses per subnet

#### **IPv4** Subnet

192.168.1.1 (network)

192.168.1.255 (broadcast)

## **Types of Unicast Addresses**



**Global Unicast Address** 

2001:5c0:8fff:3::3f53

Types of IPv6 unicast addresses:

- ¬¬ global unicast,
- ¬¬ link-local unicast, and
- ¬¬ site-local unicast.

## **IPv6 Global Unicast Address**

Global unicast address: 48-bit network prefix, 16-bit subnet ID,
 bit interface ID

Router interface: 64 bits

Current global unicast address allocation: 2000::/3 (binary 001)



**Global Unicast Address** 


2001:5c0:8fff:3::1

### **IPv6 Global Unicast Address**

\*IPv6 global unicast address (like) IPv4 global unicast address

\*Plan network in hierarchy

\*Limit routing table entries



```
Ethernet adapter Ethernet:
  Media State . . . . . . . . . . . Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 2:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 13:
  Media State . . . . . . . . . . . . Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Wi-Fi:
  Connection-specific DNS Suffix . :
  IPv6 Address. . . . . . . . . . . . 2601:642:c201:bd::478d
  IPv6 Address. . . . . . . . . . . . . . . 2601:642:c201:bd:fced:f576:4c8d:11f7
  Temporary IPv6 Address. . . . . : 2601:642:c201:bd:c5f4:62a3:c9cd:500b
  Link-local IPv6 Address . . . . : fe80::fced:f576:4c8d:11f7%9
  IPv4 Address. . . . . . . . . . . . . . . 10.0.0.118
  Default Gateway . . . . . . . : fe80::5a19:f8ff:fef4:a74e%9
                                    10.0.0.1
Ethernet adapter Bluetooth Network Connection:
```

Media State . . . . . . . . . . . . Media disconnected

Connection-specific DNS Suffix .:

### **Global Unicast Network Prefix**




**Global Unicast Address** 

2001:5c0:8fff:3::3f53

- \*Network Prefix: First part of an IPv6 address.
- \*Best practices: 48 bits

### **Global Unicast Subnet Prefix**


- Subnet prefix: standard is 16 bits
- 65,535 subnets



**Global Unicast Address** 

2001:5c0:8fff:0003::35f3

## **Global Unicast Interface ID (IID)**



Global Unicast Address

2001:5c0:8fff:3::3f53


### **IPv6 Private Addresses**

\*Link-local or site-local

\*Never routed outside a company or link

Start with hex FE then 8 to F (1111 1110 1)

Most common: FE80 (link-local)



**FE8n – FEFn = Private Addresses** 

### **Link-Local Unicast Address**

\*IPv6 devices always have linklocal address

\*IPv6 devices use link-local to communicate with 'on-link' devices

\*IPv6 routers must not forward link-local packets

10 Bits	54 Bits	64 Bits
1111111010	zeroes	Interface ID

**Sample Link-Local Address** 

fe80::211:d8ff:fe39:292b

## **Link-Local Address Explained**

\*Why do you need link-local addresses?

\*How do you get a linklocal address? Who am I? IPv6 Stateless autoconfiguration

FE8n - FEBn = Link Local

#### **Site-Local Unicast Addresses**

\*IPv4 site-local private addresses = 10.0.0.0/80.0/12 or 192.168.0.0/16

Site-local address + NAT used for topology hiding

•IPv6 site-local unicast deprecated

\*Site scope multicast still available



**FECn - FEFn = Site Local** 

## **IPv6 Reserved Addresses**

\*Defined by the IETF

#### **Includes:**

- Unspecified,
- Loopback and
- IPv4 Embedded addresses

#### See:

http://www.iana.org/assignments/ipv6-address-space/ipv6-address-space.xml

:: /8 = Reserved


## **IPv6 Unspecified Address**

\*Who am I?

\*IPv6 unspecified address.

Stateless Autoconfiguration

Represented as ::



164 ADCD PACKET 00000004 08:14:04.416323 Packet Trace

From Interface : ETH1 Device: LCS Ethernet Full=342
Tod Clock : 2006/01/06 08:14:04.416317 Intfx: 4

Sequence # : 0 Flags: Pkt

IpHeader: Version: 4 Header Length: 20

Tos : 00 QOS: Routine Normal Service

Packet Length: 342 ID Number: 0000

Fragment : Offset: 0

Source : 0.0.0.0

**Destination** : 255.255.255

**UDP** 

Source Port : 68 (bootpc) Destination Port: 67 (bootps)

Datagram Length : 322 CheckSum: 93B0 FFFF

Client IP : 0.0.0.0 Your IP: 0.0.0.0 Server IP : 0.0.0.0 Gateway: 0.0.0.0

Client HW Addr : 0013D38D61FB0000000000000000000 Flags: 0

Server Host Name: Boot FileName :

Vendor Info : 638253633501033D07010013D38D61FB3204C0A801650C0C42617272792D636F Vendor Info : 6D706171511000000042617272792D636F6D7061712E3C084D53465420352E30

DHCPMSG : DhcpREQUEST

CLIENTID : 7 010013D38D61FB


REQIPADDR : 192.168.1.101

**HOSTNAME** : Barry-compaq

DHCPDDNS : 16 00000042617272792D636F6D7061712E

CLASSID : MSFT 5.0 PARMLIST : 11 options


## **IPv6 Stateless Autoconfiguration**



## **Loopback Address**


•IPv6 loopback address is 0:0:0:0:0:0:0:1 (::1)

- \*Acts like IPv4 loopback.
  - Can't be assigned to physical interface.
  - Used by local applications
  - Can't travel outside node
  - Can't be forwarded by router



#### **IPv4 Addresses in IPv6**

- ¬¬¬ From reserved space (0000::/8)
- ¬¬ IPv4 Mapped (Embedded) IPv6 Addresses.
- ¬¬ Last 32 bits = IPv4 address
- ¬ Shown in IPv4 notation
- A May see on IBM mainframe applications



**IPv4 Mapped IPv6 Address** 

::ffff:192.168.0.1

IPv4 Compatible IPv6 Address
::197 16 0.1


## **IPv6 Multicast**

In IPv6, multicasting used widely

•Multicast is like a newsletter subscription.

Devices belong to a multicast group

•IPv4 multicast uses Class D range: (224.xx.xx.xx - 239.xx.xx.xx)



## **IPv6** Multicast Scope

\*IPv6 multicast addresses start with FF.

Last 4 bits is scope. (Ex. FF01, FF02, etc).

\*FF01:: means on same interface

\*FF02:: means on same link

\*FF05:: means in the same site

\*FF0E:: means in the Internet.

(From RFC 4291)

## **Common IPv6 Multicast Groups**

•Multicast addresses are registered with the Internet Assigned Numbers Authority (IANA).

#### See:

http://www.iana.org/assignments/ipv6-multicast-addresses/ipv6-multicast-addresses.xml

#### <u>IPv6 multicast address</u> <u>Description</u>

FF02::1 The all-nodes address

FF02::2 The all-routers address

FF02::5 The all-Open Shortest Path First (OSPF) routers address

FF02::6 The all-OSPF designated routers address

## **IPv6 Address Summary**

2001:5c0:8fff:fffe::1

\*IPv6 is more than a bigger address!

Many changes to protocol.

2001::11:22:33:44

ff02::1



fe80::211:d8ff:fe39:292b

fe80::192:168:1:100

fe80::169.254.1.100

# Questions?